



Installation Instructions for Decorative Backsplash

1. Measure the total length of the piece you wish to install. Cut the piece at the desired length, with regular scissors.
2. Fit the piece under the cupboards
3. Apply glue (contact cement) on the back of the backsplash and on the wall (where you are going to attach it).
4. Let the glue dry till it becomes “tacky” and attach the piece to the wall, squeezing out all the air from behind of the backsplash.

You are done! Now you can cover the edges of the backsplash with metal/wood/plastic edging and start enjoying your new backsplash!

If you have any further questions, please contact us on info@euro-deco.net

www.euro-deco.net